

09411 7Pc. A/C & Fuel Line Disconnect Set



- Used for disassembling A/C pipe and oil pipe
- Applicable pipe diameters:
- 1/4"(6mm), 5/16"(8mm), 3/8"(9.5mm), 1/2"(12.7mm), 5/8"(16mm), 3/4"(19mm), 7/8"(22mm)

No.			
09411	6	72	11.2

▲ Excluded from lifetime warranty terms.

09706 12Pc. Transmission Repair Tool Set



Contents

- Jaw and locking ring
- Bearing
- Mandrel
- Pulling device
- Thrust washer
- Quad4 drawing pin
- GM3.1 drawing pin
- Quad4 screw-shaped drawing pin
- Ford4.6 Modular screw-shaped drawing pin
- Drawing pins for other vehicle model
- GM.31 screw-shaped drawing pin
- Buckle-type head
- Used to remove and install power steering pulley on the alternator of most domestic cars

No.			
09706	-	18	16.5

▲ Warranty terms of tool set comply with the individual product.

09709 5Pc. Hook & Pick Set




- 5-piece set including an extended magnetic grip to be absorbed at places within easy reach
- Heat treated picks for improved durability
- Use picks to pull O-Rings, seals and cotter pins quickly and easily

No.			
09709	20	200	9.7

▲ Warranty terms of tool set comply with the individual product.

97511 Valve Seal Removal Pliers 10"



- For removing or installation of valve stem seals and valve spring

No.	Spec. (mm)			
97511	250	6	48	20

Bearing Separator



- Used to pull and remove bearings
- Made of Cr-Mo

No.	Spec. (mm)			
90657	30-50	1	25	17.5
90658	50-75	-	12	17.6

▲ Excluded from lifetime warranty terms.