


OSH 20

THREAD SIZE				
SIZE	H	M	F	N
20	9	R ¼	Rc ¼	-
30	11	R ⅝	Rc ⅝	-
40	15	R ½	Rc ½	-
400	15	R ½	Rc ½	-
600	21	R ¾	Rc ¾	-
800	27	R1	Rc 1	-
08	-	-	-	8×5
10	-	-	-	10×6.5
12	-	-	-	12×8



Steel Coupler

SH



MODEL(T)
Hose Stem
SH 20
SH 30
SH 40
SH 400
SH 600
SH 800

SM



MODEL(T)
Thread R
SM 20
SM 30
SM 40
SM 400
SM 600
SM 800

SF



MODEL(T)
Thread Rc
SF 20
SF 30
SF 40
SF 400
SF 600
SF 800

SN



MODEL(T)
Hose Nut(φT)
SN 08
SN 10
SN 12

PH



MODEL(T)
Hose Stem
PH 20
PH 30
PH 40
PH 400
PH 600
PH 800

PM



MODEL(T)
Thread R
PM 20
PM 30
PM 40
PM 400
PM 600
PM 800

PF



MODEL(T)
Thread Rc
PF 20
PF 30
PF 40
PF 400
PF 600
PF 800

PN



MODEL(T)
Hose Nut(φT)
PN 08
PN 10
PN 12

Steel One - Touch Coupler

OSH



MODEL(T)
Hose Stem
OSH 20
OSH 30
OSH 40

OSM



MODEL(T)
Thread R
OSM 20
OSM 30
OSM 40

OSF



MODEL(T)
Thread Rc
OSF 20
OSF 30
OSF 40

OSN



MODEL(T)
Hose Nut(φT)
OSN 08
OSN 10
OSN 12

Coupler BSBM

BSH



MODEL(T)
Hose Stem
BSH 20
BSH 30
BSH 40

BSM



MODEL(T)
Thread R
BSM 20
BSM 30
BSM 40

BSF



MODEL(T)
Thread Rc
BSF 20
BSF 30
BSF 40

BPH



MODEL(T)
Hose Stem
BPH 20
BPH 30
BPH 40

BPM



MODEL(T)
Thread R
BPM 20
BPM 30
BPM 40


BPF



MODEL(T)
Thread Rc
BPF 20
BPF 30
BPF 40

Mold Coupler BSBM

KSH



MODEL(T)
Hose Stem
KSH 20
KSH 30A
KSH 30

KSM



MODEL(T)
Thread R
KSM 10
KSM 20
KSM 30

KSF



MODEL(T)
Thread Rc
KSF 10
KSF 20
KSF 30

KPH




MODEL(T)
Hose Stem
KPH 20
KPH 30A
KPH 30

KPM



MODEL(T)
Thread R
KPM 10
KPM 20
KPM 30

KPF



MODEL(T)
Thread Rc
KPF 10
KPF 20
KPF 30