

## 1/2" Dr. 6Pt. Socket

1/2"



← L →

No.	⊘	L(mm)			
13101	5/16"	37.8	4	-	-
13102	3/8"	37.8	6	-	-
13103	7/16"	37.8	6	-	-
13104	1/2"	37.8	6	-	-
13105	9/16"	37.8	6	-	-
13106	5/8"	37.8	6	-	-
13107	11/16"	37.8	6	-	-
13108	3/4"	37.8	6	-	-
13109	13/16"	37.8	4	-	-
13110	7/8"	37.8	4	-	-
13111	15/16"	37.8	4	-	-
13112	1"	37.8	4	-	-
13113	1-1/16"	37.8	4	-	-
13114	1-1/8"	37.8	4	-	-
13115	1-1/4"	37.8	2	-	-

▲ These sockets should never be used on power drivers, pneumatic impact wrench and/or extenders.

## 1/2" Dr. 6Pt. Deep Socket

1/2"



← L →

No.	⊘	L(mm)			
13201	3/8"	77	6	-	-
13202	7/16"	77	6	-	-
13203	1/2"	77	6	-	-
13204	9/16"	77	6	-	-
13205	5/8"	77	6	-	-
13206	11/16"	77	6	-	-
13207	3/4"	77	6	-	-
13208	13/16"	77	4	-	-
13209	7/8"	77	4	-	-
13210	15/16"	77	4	-	-
13211	1"	77	4	-	-
13212	1-1/16"	77	4	-	-
13213	1-1/8"	77	4	-	-
13214	1-1/4"	77	6	-	-

▲ These sockets should never be used on power drivers, pneumatic impact wrench and/or extenders.

## 1/2" Dr. 6Pt. Socket

1/2"



← L →

No.	⊘ (mm)	L(mm)			
13319	8	38	6	-	-
13320	9	38	6	-	-
13301	10	38	6	-	-
13302	11	38	6	-	-
13303	12	38	6	-	-
13304	13	38	6	-	-
13305	14	38	6	-	-
13306	15	38	6	-	-
13307	16	38	6	-	-
13308	17	38	6	-	-
13309	18	38	6	-	-
13310	19	38	6	-	-
13311	20	38	4	-	-
13312	21	38	4	-	-
13313	22	38	4	-	-
13314	23	38	4	-	-
13315	24	38	4	-	-
13316	27	38	4	-	-
13317	30	38	2	-	-
13318	32	38	2	-	-
13321	34	38	2	-	-

▲ These sockets should never be used on power drivers, pneumatic impact wrench and/or extenders.