

Unit: mm

http://en.**pisco.co.jp** 

CAD

Model code	Model code	R	А	В	L	øΡ	Tube end C	Е	Hex. H	Orifice bore (ømm)	Weight (g)	CAD file name
PL4-M5 4		M5×0.8	2.8 [3]	16	18.2 [18]			17.7	8	2.4	5.7	PL4-M5_(C)
PL4-M64	4	M6 × 1	3.8	20	21.2	10	14.9	18.7	10	2.8	8	PL4-M6_(C)
PL4-01 4	4	R1/8	8	22	23	10	14.9	10.7	10	2.0	10	PL4-01_
PL4-024		R1/4	11	29	28			20.7	14	2.8	18	PL4-02_
PL6-M54		M5×0.8	2.8 [3]	19.5	23 [22.8]					2.4	8.9	PL6-M5_(C)
PL6-M64		M6 × 1	3.8	20.5	23			20.3	10	3	8	PL6-M6_(C)
PL6-01 4	6	R1/8	8	22.5	24.8	12.5	17			4.2	11	PL6-01_
PL6-024		R1/4	11	28	28.2			21.8	14	4.3	19	PL6-02_
PL6-034		R3/8	12	31.5	31.4			23.8	17	4.5	30	PL6-03_
PL8-01 4 *		R1/8	8	24	27.3			22.7	12	6	14	PL8-01_
PL8-02@*	8	R1/4	11	28	29.2	14.5	18.1	23.7	14	6.7	20	PL8-02_
PL8-03@*		R3/8	12	31	31.9			24.7	17	0.7	31	PL8-03_
PL10-01 4		R1/8	8	25	29.8			25.5	12	6	18	PL10-01_
PL10-02@*	10	R1/4	11	28.5	31.2	17.5	20.2	26	14	8	23	PL10-02_
PL10-03@*	10	R3/8	12	32	34.4	17.5	20.2	27	17	8.3	34	PL10-03_
PL10-04 4		R1/2	15	36	36.6			27.5	21	0.5	57	PL10-04_
PL12-02 4		R1/4	11	29.8	34.2			29	14	8	27	PL12-02_
PL12-034	12	R3/8	12	32.5	36.7	21	23.4	29.7	17	10	38	PL12-03_
PL12-04 4		R1/2	15	36.5	38.8			30.7	21	10.3	61	PL12-04_
PL16-034	16	R3/8	11	47	53.2	25	24.1	22.1	22	11	74	PL16-03_
PL16-04 4	16	R1/2	15	51	55.3	25	24.1	33.1	22	13	79	PL16-04_

- \* 1. 4 in Model code / Replaced with "W" for Light-gray color, "-C" for Clean-room package, "W-C" for Light-gray color and Cleanroom packge, "-UC" for Clean-wash and Clean-room package
- ※ 2. "L" is a reference value for height dimension after tightening taper thread.
- ※ 3. Space saving types are available for model codes with \* mark. See page 762.
- \* 4. Dimensions in [] are for clean-room and clean-wash package products
- \* 5. Orifice bore is the smallest passage converted in terms of the diameter.

Minimal

Minimal Series

Stop Fitting Series

Rotary Series

> Twist-Proof Fitting

Louping





# Push-In Fitting Type for Pneumatic Piping Tube Fitting Standard Series


- Push-in fitting for General Pneumatic Piping.
- Redesigned 17 models, realized weight saving. (PC, PCF, POC, PM, PMF, PL, PLL, PLH, PLF, PVX, PAX, PB, PD, PX, PRX, PKD, PKVD)
  - Wide Variety of Products.
  - Rotatable Resin Body after Installation.
    - Centralized Piping.

Triple type (PKD, PKG, PKJ) and twin triple type (PKVD, PKVG) are compact designed to achieve centralized piping.

Optional Selection of Clean-Room Package
 and Clean-wash Package.



# ■ Model Designation (Example)



# ① Type

Code	Туре	Code	Type	Code	Туре	Code	Type
С	Straight	ОС	Inner Hex. Straight		Elbow	LL	Long Elbow
LH	45° Elbow	Н	Single Banjo	OL	Hex. Holed Banjo	В	Branch Tee
D	Run Tee	Х	Branch Y	VX	Tripod Elbow	AX	Branch Elbow
Α	Twin Banjo	RX	Double Branch Y	HW	Double Banjo	HT	Triple Banjo
AW	Double Twin Banjo	ΑT	Triple Twin Banjo	CF	Female Straight	MF	Bulkhead Female Straight
LF	Female Elbow	KD	Triple Run Tee	KVD	Twin Triple Run Tee	AF	Link-up Twin Banjo
HF	Link-up Banjo	U	Union Straight	Е	Union Tee	V	Union Elbow
Υ	Union Y	М	Bulkhead Union	MP	Bulkhead Union P	ML	Bulkhead Union Elbow
VU	Tripod Union	AU	Branch Union Elbow	ZA	Union Cross	G	Unequal Union Straight
EG	Unequal Union Tee	RG	Unequal Double Y	W	Unequal Union Y	KG	Unequal Triple Tee
KVG	Unequal Twin Triple Tee	ZB	Unequal Cross	ZC	Reducing Cross	GJ	Unequal Plug-in Straight
LJ	Plug-in Elbow	LGJ	Unequal Plug-in Elbow	LLGJ	Unequal Plug-in Long Elbow	LHJ	45° Plug-in Elbow
LLJ	Long Plug-in Elbow	YJ	Plug-in Y	WJ	Unequal Plug-in Y	KJ	Plug-in Triple Tee
RJ	Plug-in Double Y	F	Extension Screw Adaptor	FF	Unequal Screw Union	IJ	Union Stem
IG	Unequal Union Stem	TJ	PT Jack	PF	Cap	Р	Plug

<sup>\*</sup> parts are redesigned models.

2 Tube dia. (\* In case that 2 indicates thread, select thread size from table 3)

Tube dia.	mm size						inch size  5/32 3/16 1/4 5/16 3/8 1/2 5.  ø3.97 ø4.76 ø6.35 ø7.94 ø9.53 ø12.7 ø18						
Code	4	6	8	10	12	16	5/32	3/16	1/4	1/2	5/8		
Size (mm)	ø4	ø6	ø8	ø10	ø12	ø16	ø3.97	ø4.76	ø6.35	ø7.94	ø9.53	ø12.7	ø15.88

③ Thread size (\* In case that ③ indicates tube dia., select tube dia. from table ②)

Thread size	Metric thre	ead (mm)		Taper pipe thread								
Code	M5	М6	01	02	03	04						
Size	M5 × 0.8	$M6 \times 1$	R1/8	R1/4	R3/8	R1/2						
Thread size	UNF thread (mm)			NPT thread								
Code	U10U	N1U	N2U	N3U	N4U	NOU						
Size	10-32UNF	NPT1/8	NPT1/4	NPT3/8	NPT1/2	NPT1/16						

<sup>\*</sup> The unit of wrench size is inch (the code suffix is "U").

# 4 Color and Packaging option

Code	Color and Package classification	Color Cor	nbination	Remark	
Code	Color and Fackage classification	Release ring(*)	Fitting body	nemark	
No code	Std.	Black	Black		
-C	Clean-room package	Light-blue	Light-gray	Optional selection	
W	Light-gray	Light-gray	Light-gray	Optional selection	
W-C	Light-gray + Clean-room pkg.	Light-gray	Light-gray	Optional selection	
-UC	Clean-wash and Clean-room pkg.	Light-blue	Light-gray	Optional selection	

<sup>\* .</sup> Release-ring color is white for inch-size products.

Standard Series


Block and Coupling

Specifications

Fluid medium	Air / Water ( ※ )
Max. operating pressure	1.0MPa
Max. vacuum	-100kPa
Operating temp. range	0~60°C (No freezing)

- - \* . Make sure to follow the instructions below when the fluid medium is water.
    - 1. Surge pressure must be controlled lower than max, operating pressure.
    - 2. Tap water can be used. Consult with PISCO for using other kind of water.
    - 3. Be sure to place Insert Ring into the tube edge when using water as a fluid medium.

# ■ Construction (Elbow: PL)



\* Clean-room package or Clean-wash package: POM gasket

♠ Detailed Safety Instructions I

Before using PISCO products, be sure to read "Safety Instructions" and "Common Safety Instructions for Products Listed in This Catalog" on page 23 to 28 and "Common Safety Instructions for Fittings" on page 33 to 34.

# Warning

1. When the fluid medium is water, do not use Tube Fitting Standard Series unless the operating environment meets all the described specifications in the catalog. Otherwise, it may cause damage to the products, the escape of tubes and a fluid leakage.

# Caution

- 1. To adjust the direction of the elbow fitting after fixing PML (Bulkhead Union Elbow) type. turn it in the clock-wise (right) direction.
- 2. Attach a rubber washer to the aluminum nut side when installing PML (Bulkhead Union Elbow) type. The bulkhead parts may be loosened or the rubber washer may deform if attaching it to the hexagonal side.

# Caution (Clean-room package, clean-wash package)

1. As for Push-In Fitting, the functional part where tube is inserted may slightly slide due to an internal pressure change and this may generate dusts. Avoid using the fitting in the clean room of ISO class from 1 to 5. Under the vibrating condition, check the amount of dust generated from the fitting and tubes, by using actual facilities.

# Caution (Clean-wash package)

1. Tube insertion into the push-in fitting with clean-wash spec. is tigher than that of standard spec. due to its oil-free specification. Make sure to insert tube up to tube end.



# ■ Standard Size List I

# Connection: Thread ⇔ Tube (P44~P68)

T	Dama	Thursdains						Tub	e (	D.D	١.				
Туре	Page	Thread size	4	6	8	10	12	16	5/32	3/16	1/4	5/16	3/8	1/2	5/8
PC Straight	P.44	M5 × 0.8		0					0	0	0				
		M6 × 1													
		R1/8	0	0	0	0				0	0		0	_	
		R1/4	0	0			0		0	0	0	0	0	0	
		R3/8		0	0	0	0	0			0	0	0	0	0
POC Inner Hex. Straight	D.45	R1/2 M5 × 0.8		0		0	0	O					0	0	0
POG IIIIRI NEX. Straigili	F.45	M6 × 1		0											
		R1/8	0	O	0	0					0	0			
		R1/4		0			0					0	0		
		R3/8			0	0	0	0				0	0		
		R1/2				0	0	0					0		
Female Straight	P.46	M5 × 0.8	0	0											
		Rc1/8	0	0						0	0	0			
		Rc1/4	0	0	0	0	0		0	0	0	0	0	0	
		Rc3/8		0	0	0					0	0	0	0	
ESTERN BUILDING BUILDING	D. 47	Rc1/2		-			0	0						0	
<b>PMF</b> Bulkhead Female Straight	P.47	Rc1/8		0	00		0								
		Rc1/4 Rc3/8	0	0	0	0	0	0							
		Rc1/2		0	0	0	ŏ	ŏ							
Elbow	P48	M5 × 0.8	0	0					0	0	0				
	1	M6 × 1	0	0					_	_	_				
		R1/8	0	0	0	0			0	0	0	0	0		
		R1/4	0	0	0	0	0		0	0	0	0	0	0	
		R3/8		0	0	0	0	•			0	0	0	0	•
		R1/2				0	0	•					0	0	•
PLL Long Elbow	P.50	$M5 \times 0.8$		0											
		R1/8	0	0	0	0			0	0	0	0	0		
		R1/4	0	-	0	0	0		0	0	0	0	0		
		R3/8 R1/2		0	0	0	0	•			0	0	00	0	
45°Elbow	P.51	R1/8			0	0	0	_					0	0	
40 LIDOW	1.01	R1/4			0		0								
		R3/8			0	0	0	•							
		R1/2				0	0	•							
POL Hex. Holed Banjo	P.51	M5 × 0.8	•												
		R1/8		•	•										
		R1/4		•	•	•									
		R3/8			•	•	•								
PLFI Female Elbow	DEO	R1/2		0			•		0	0					
PIE Female Elbow	P.52	M5 × 0.8 M6 × 1	0	0					0	0	0				
		Rc1/8	0	0					0	0	0	0			
		Rc1/4	0	Õ	Õ	0	0		Õ	Õ	Õ	ŏ	0	0	
		Rc3/8		0	0	0	0			0	0	0	0	0	
		Rc1/2				O	0						0	O	
PAX Branch Elbow	P.53	M5 × 0.8	0	0											
PVX Tripod Elbow	P.54	M6 × 1	0	0											
		R1/8	0			0									
		R1/4	0	0	0	0	0								
		R3/8		0	0	0	0								
		R1/2				0	0								

							_		_						_
Type	Page	Thread size	4	6	8	10	12			0.D		EHO	2/0	1/0	E/0
PH Single Banjo	P55	M5 × 0.8	•	•	0	10	12	10	0/32	a/10	1/4	3/10	3/0	1/2	3/0
omgio banyo	1.00	M6 × 1	•	ě					_	_	_				
		R1/8	ě	ě	•				•	•	•	•			
		R1/4		ě	•	•			Ĭ	ě	•	ě	•		
		R3/8			•	•	•	•				•	•	•	
		R1/2					•	•						•	
PHW Double Banjo	P.57	R1/8	lacktriangle	•	•						•				
PHT Triple Banjo	P.58		•	•	•	•	•				•	•	•		
		R3/8	ullet	•	•	•	•				•	•	•		
		R1/2			•	•	•					•	•		
PA Twin Banjo	P.59	M5 × 0.8	•	_											
		R1/8		•											
		R1/4			•	_									
		R3/8 R1/2				•									
PAW Double Twin Banjo	P.60		_	_	_		_				•				
PAT Triple Twin Banjo		R1/4	-	-	-	•	•				-	•	•		
Triple Titill Daile	1.01	R3/8	ě	ĕ	ě	•	•				•	•	•		
		R1/2		Ī	ě	ě	ě				_	ě	ě		
PB Branch Tee	P.62	M5 × 0.8	0	0											
PD Run Tee	P.64	M6 × 1		0											
		R1/8		0		0			0		0		0		
		R1/4	0	0	0	0	0		0	0	0	0			
		R3/8		0	0	0	0				0	0	0	0	
		R1/2	_	_		0	0	•					0	0	
PX Branch Y	P.66	M5 × 0.8													
		M6 × 1 R1/8		0					0	0	0	0	0		
		R1/8	0	0	0	0	0		0	0	0	0	0	0	
		R1/4	0	0	0	0	0	•	0	0	0	0	0	0	
		R1/2		0	0	0	0	-			0	0	0	0	
Double Branch Y	P.67	R1/8	0	0									ľ		
Danie Branen 1		R1/4	0	-											

T	D	Thursdains				7	Tub	e (	D.D	).				Thread size2
Туре	Page	Thread size	4	6	8	10	12	5/32	3/16	1/4	5/16	3/8	1/2	Thread Sizez
PHE Link-up Banjo	P.56	M5 × 0.8	lacktriangle	lacktriangle				•	lacksquare	lacktriangle				M5 × 0.8
		R1/8	•	•	•			•	•	•	•			Rc1/8
		R1/4		lacktrian	•	•			lacksquare	•	•	•		Rc1/4
		R3/8			•	•	•				•	•	•	Rc3/8
		R1/2					•						•	Rc1/2
PAE Link-up Twin Banjo	P.59	M5 × 0.8	•											M5 × 0.8
		R1/8		ullet										Rc1/8
		R1/4			•									Rc1/4
						•	•							Rc3/8
		R1/2					•							Rc1/2

Type	Page	Thread size	Т	Tube O.D.1					
туре	rage	Tilleau Size	4	6	8	Tube O.D.2			
■KD Triple Run Tee	P.67	R1/8	0			6			
		R1/4	0	0		8			
		R3/8			0	10			
■KVD Twin Triple Run Tee	P.68	R1/4	0	0		8			
		R3/8	0	0		8			
		H3/6		0	0	10			
		R1/2		0	0	10			

Time	Dogo	Thread size	Tube dia.(mm)								
Туре	Page	Trileau Size	4	6	8	10					
PTJ PT Jack	P.87	M5×0.8	•	•							
		R1/8	•	•	•						
		R1/4		•	•						
		R3/8			•	•					

# Connection: Thread ⇔ Fitting (P.87) Connection: Thread ⇔ Thread (P.88 ~ P.89)

Time	Dana	Thursd size		Th	read siz	ze2	
Туре	Page	Thread size	$M5 \times 0.8$	Rc1/8	Rc1/4	Rc3/8	Rc1/2
PF Extension Screw Adaptor	P.88	M5 × 0.8	•	•			
		R1/8	•	•	•	•	
		R1/4	•	•	•	•	•
		R3/8		•	•	•	•
		R1/2					•
PFF Unequal Screw Union	P.89	Rc1/8	•				
		Rc1/4		•			
		Rc3/8		•	•		
		Rc1/2			•	•	

http://en.**pisco.co.jp** 

42

Minimal Series

Stop Fitting Series

Rotary Series

Twist-Proof Fitting Block and


Connector

Color Cap

# Connection: Tube $\Leftrightarrow$ Tube (P.69 $\sim$ P.79)

# Equal dia.

Type Page						Tut	oe (	).D.						
туре	rage	4	6	8	10	12	16	5/32	3/16	1/4	5/16	3/8	1/2	5/8
PU Union Straight	P.69	•	•	•	•	•	•	•	•	•	•	•	•	•
PM Bulkhead Union	P.70	0	0	0	0	0	0	0	0	0	0	0	0	
PMP Bulkhead Union P	P.70	•	•	•	•	•		•		•	•	•		
PV Union Elbow	P.71	•	•	•	•	•	•	•	•	•	•	•	•	
PML Bulkhead Union Elbow	P.71	•	•	•	•	•		•		•	•	•		
PAU Branch Union Elbow	P.72	•	•	•	•	•		•	•	•	•	•	•	
<b>PVU</b> Tripod Union	P.72	•	•	•	•	•		•	•	•	•	•	•	
PE Union Tee	P.73	•	•	•	•	•	•	•	•	•	•	•	•	
PY Union Y	P.75	•	•	•	•	•	•	•	•	•	•	•	•	
PZA Union Cross	P.78			•	•	•				•	•	•	•	




# Connection: Tube ⇔ Fitting(P.80 ~ P.85)

### Equal dia.

MECSU MECSU

Type	Page	1 Tube dia. (mm), Tube O.D. 4 6 8 10 12 16 5/32 1/4 5/16 3/8 1/2										
21		4	6	8								
PLJ Plug-in Elbow									•		•	
PLL Long Plug-in Elbow	P.81	•		•	•	•		•	•	•	•	•
45°Plug-in Elbow				•	•	•						
PYJ Plug-in Y	P.83	•		•					•	•	•	•

### Unequal dia.



# Connection: Fitting ⇔ Fitting (P.86)

# Equal dia.

Type Page			Tube dia. (mm) 4 6 8 10 12 16 5/32 3/16 1/4 5/16 3/8 1/2										
туре	Page	4	6	8	10	12	16	5/32	3/16	1/4	5/16	3/8	1/2
PIJ Union Stem	P.86	•	•	•	•	•	•	•	•	•	•	•	•

# Unequal dia.

T	Page	Tube dia. 1				ube						
Туре	Page	(mm)	4	6	8	10	12	5/32	3/16	1/4	5/16	3/8
PIG Unequal Union Stem	P.86	6	•									
		8	•	•								
		10		•	•							
		12			•	•						
		16				•	•					
		3/16						•				
		1/4						•	lacktriangle			
		5/16								•		
		3/8									•	
		1/2										•

# Plug (P.90)

Type	Pogo						Tul	oe (	D.D.					
туре	Page	4	6	8	10	12	16	1/8	5/32	3/16	1/4	5/16	3/8	1/2
PPF Cap	P.90	•	•	•	•	•	•	•	•	•	•	•		•
PP Plug	P.90	•	•	•	•	•	•		•	•	•	•	•	•

# Fitting Series

# **MECSU**

# Tube Fitting

# How to insert and disconnect

### 1. How to insert and disconnect tubes

### 1 Tube insertion

Insert a tube into Push-in fitting up to the tube end. Lock-claws bite the tube and fix it automatically, then the elastic sleeve seals around the tube.

Refer to "6. Instructions for Tube Insertion" under "Common Safety Instructions for Products Listed in This Catalog".



### 2 Tube disconnection

The tube is disconnected by pushing release-ring to release Lock-claws. Make sure to stop air supply before the tube disconnection.



# 2. How to tighten thread

# ① Tightening thread

There are two ways to tighten thread. Use a spanner or an impact wrench for a hexagonal-column. A hex key is for an inner hexagonal socket. Inner hexagonal type can save spaces.

Refer to "Table 2: Tightening torque / Sealock color / Gasket materials" under "8. Instructions for Installing a fitting" in "Common Safety Instructions for Products Listed in This Catalog".





# ■ Applicable Tube and Related Products

Polyurethane Tube ....... P.596

Nylon Tube ......P.608

Fluororesin Tube with clean-room package......P.638

Polyurethane Tube with clean-room package ......... P.642



# ⚠ Safety Instructions

This Safety Instructions aim to prevent personal injury and damage to properties by requiring proper use of PISCO products.

Be certain to follow ISO 4414 and JIS B 8370.

ISO 4414: Pneumatic fluid power···General rules and safety requirements for system and their components.

JIS B 8370: General rules and safety requirements for systems and their components.

This Safety instructions are classified into "Danger", "Warning" and "Caution", depending on the degree of danger or damages caused by improper use of PISCO products.

Danger Hazardous conditions. It can cause death or serious personal injury.

Warning Hazardous conditions depending on usages. Improper Use of PISCO products can case death or serious personal injury.

1 Caution Hazardous conditions depending on usages. Improper use of PISCO products can cause personal injury or damages to properties.

# ↑ Warning I

- 1. Selection of pneumatic products.
  - ① A user who is a pneumatic system designer or has sufficient experience and technical expertise should select PISCO products.
  - 2 Due to wide variety of operating conditions and applications for PISCO products, carry out the analysis and evaluation on PISCO products. The pneumatic system designer is solely responsible for assuring that the user's requirements are met and that the application presents no health or safety hazards. All designers are required to fully understand the specifications of PISCO products and constitute all systems based on the latest catalog or information, considering any malfunction.
- 2. The pneumatic equipments shall be handled by a person having enough knowledge and experiences.
  - ① Improper use of compressed air is dangerous. Assembly, operation and maintenance of machines using pneumatic equipment should be conducted by a person with enough knowledge and experience.
- 3. Do not operate machine / equipment or remove pneumatic equipment until safety is confirmed.
  - ① Make sure that preventive measures against falling work-pieces or sudden movements of machine are completed before inspection or maintenance of these machine
  - ② Make sure the above preventive measures are completed. A compressed air supply and the power supply to the machine must be off, and also the compressed air in the systems must be exhausted.





③ Restart the machines with care after ensuring to take all preventive measures against sudden movements.

# Warranty

- 1. When the product produces a trouble, which is caused by our responsibility, we will carry out either one of the following measures immediately.
  - ① Free-of-charge replacement of same product
  - ② Free-of-charge repair of the product at our factory

# Disclaimer

When a cause of the trouble/malfunction applies to any of the following items, it is excluded from the coverage of the above warranty.

- ①. A case by a natural disaster, a fire except our responsibility, the act by the third person/party, the intention or fault of the customer.
- ②. A case when a product is used out of the specific range or in a method listed in the product catalog or the instruction manual.
- ③. A case by the remodeling of the product or by a change of structure, performance, or specifications which PISCO is not involved in.
- ④. A case by the event that is unpredictable by the evaluations and the measures at the time on or before the initial delivery.
- ⑤. A case caused by the phenomenon that is able to be evaded if your machine or equipment has functions or structures that are comprised in a common sense when this product is incorporated in your machine or equipment.

Additionally, the above warranty is limited simply to the product itself. The damage induced by the trouble of the product will not be compensated.



# ⚠ Common Safety Instructions for Products Listed in This Catalog

PISCO products are designed and manufactured for use in general industrial machines.

# 

- 1. Do not use PISCO products for the following applications.
  - ① Equipment used for maintaining / handling human life and body.
  - 2 Equipment used for moving / transporting human.
  - 3 Equipment specifically used for safety purposes.

# 

- 1. Do not use PISCO products under the following conditions.
  - ① Beyond the specifications or conditions stated in the catalog, or the instructions.
  - ② Use at outdoors.
  - ③ Excessive vibrations and impacts.
  - ④ Exposure / adhere to corrosive gas, flammable gas, chemicals, seawater, water and vapor.
    - \* Some products can be used under the condition above(4). Refer to the details of specifications and conditions of each product.
- 2. Do not disassemble or modify PISCO products, which affect the performance, function, and basic structure of the product.
- 3. Do not touch the release-ring of a push-in fitting when there is a working pressure. The lock may be released by the physical contact, and tube may fly out or slip out.
- 4. Frequent switchover of compressed air may generate heat, and there is a risk of causing burn injury.
- 5. Avoid any load on PISCO products, such as, a tensile strength, twisting and bending.
- 6. As for applications where threads or tubes swing / rotate, use Rotary Joints, High Rotary Joints or Multi-Circuit Rotary Block only. The other PISCO products can be damaged in these applications.
- 7. Use only Die Temperature Control Fitting Series, Tube Fitting Stainless SUS316 Series, Tube Fitting Stainless SUS316 Compression Fitting Series or Tube Fitting Brass Series under the condition of over 60°C (140 °F) water or heat medium oil. Other PISCO products can be damaged by heat and hydrolysis under the condition above.
- 8. As for the condition required to dissipate static electricity or provide an antistatic performance, use EG series fitting and antistatic products only, and do not use other PISCO products. There is a risk that static electricity





can cause system defects or failures.

- 9. Use only Fittings with a characteristic of spatter-proof such as Antispatter or Brass series in a place where flame and weld spatter is produced. There is a risk of causing fire by sparks.
- 10. Turn off the power supply, stop the air supply to PISCO products, and make sure there is no residual air pressure in the pipes before maintenance and inspection. Follow the instructions below in order to ensure the safety.
  - ① Make sure the safety of all systems related to PISCO products before maintenance.
  - ② Restart of operation after maintenance shall be proceeded with care after ensuring the safety of the system by preventive measures against unexpected movements of machines and devices where pneumatic equipment is used.
  - 3 Keep enough space for maintenance when designing a circuit.
- 11. Take safety measures such as providing a protection cover if there is a risk of causing damages or fire on machine / facilities by a fluid leakage.

# 


- 1. Remove dusts or drain before piping. They may get into the peripheral machine / facilities and cause malfunction.
- 2. When inserting an ultra-soft tube into a push-in fitting, make sure to place an Insert Ring into the tube edge. There is a risk of causing the escape of the tube and a fluid leakage without using an Insert Ring.
- 3. The product incorporating NBR as seal rubber material has a risk of malfunction caused by ozone crack. Ozone exists in high concentrations in static elimination air, clean-room, and near the high-voltage motors, etc. As a countermeasure, material change from NBR to HNBR or FKM is necessary.
- 4. Special option "Oil-free" products may cause a very small amount of a fluid leakage. When a fluid medium is liquid or the products are required to be used in harsh environments, contact us for further information.
- 5. In case of using non-PISCO brand tubes, make sure the tolerance of the outer tube diameter and tube hardness are within the limits of Table 1.
  - Table 1. Tube O.D. Tolerance


mm size	Nylon tube (SHORE D63)	Polyurethane tube (SHORE A98)	inch size	Nylon tube (SHORE D63)	Polyurethane tube (SHORE A98)
ø1.8mm	_	± 0.05mm	ø1/8	± 0.1mm	± 0.15mm
ø2mm	_	± 0.05mm	ø5/32	± 0.1mm	± 0.15mm
ø3mm	_	± 0.15mm	ø3/16	± 0.1mm	± 0.15mm
ø4mm	± 0.1mm	± 0.15mm	ø1/4	± 0.1mm	± 0.15mm
ø6mm	± 0.1mm	± 0.15mm	ø5/16	± 0.1mm	± 0.15mm
ø8mm	± 0.1mm	± 0.15mm	ø3/8	± 0.1mm	± 0.15mm
ø10mm	± 0.1mm	± 0.15mm	ø1/2	± 0.1mm	± 0.15mm
ø12mm	± 0.1mm	± 0.15mm	ø5/8	± 0.1mm	± 0.15mm
Ø16mm	± 0.1mm	± 0.15mm			



# 6. Instructions for Tube Insertion

- ① Make sure that the cut end surface of the tube is at a right angle without a scratch on the tube surface or deformations.
- ② When inserting a tube, the tube needs to be inserted fully into the pushin fitting until the tubing edge touches the tube end of the fitting as shown in the figure below. Otherwise, there is a risk of leakage.





Tube is not fully inserted up to tube end.

- 3 After inserting the tube, make sure it is inserted properly and not to be disconnected by pulling it moderately.
- \*\*. When inserting tubes, Lock-claws may be hardly visible in the hole, observed from the front face of the release-ring. But it does not mean the tube will surely escape. Major causes of the tube escape are the followings; ① Shear drop of the lock-claws edge ② The problem of tube diameter (usually small). Therefore, follow the above instructions from ① to ③, even lock-claws is hardly visible.

# 7. Instructions for Tube Disconnection

- ① Make sure there is no air pressure inside of the tube, before disconnecting it.
- ② Push the release-ring of the push-in fitting evenly and deep enough to pull out the tube toward oneself. By insufficient pushing of the releasering, the tube may not be pulled out or damaged by scratch, and tube shavings may remain inside of the fitting, which may cause the leakage later.

# 8. Instructions for installing a fitting

- ① When installing a fitting, use proper tools to tighten a hexagonal-column or an inner hexagonal socket. When inserting a hex key into the inner hexagonal socket of the fitting, be careful so that the tool does not touch lock-claws. The deformation of lock-claws may result in a poor performance of systems or an escape of the tube.
- ② Refer to Table 2 which shows the tightening torque. Do not exceed these limits to tighten a thread. Excessive tightening may break the thread part or deform the gasket to cause a fluid leakage. Tightening thread with tightening torque lower than these limits may cause a loosened thread or a fluid leakage.
- ③ Adjust the tube direction while tightening thread within these limits, since some PISCO products are not rotatable after the installation.





# ● Table 2: Tightening torque / Sealock color / Gasket materials

Thread type	Thread size	Tightening torque	Sealock color	Gasket material
	$M3 \times 0.5$	0.7N·m		ODGG NDD
	$M5 \times 0.8$	1 ~ 1.5N·m		SPCC+NBR SUS304+NBR
	$M6 \times 1$	2 ~ 2.7N·m		000004+11011
Metric thread	$M3 \times 0.5$	0.7N·m	_	
	$M5 \times 0.8$	1 ~ 1.5N·m		POM
	$M6 \times 0.75$	0.8 ~ 1N·m		FOIN
	$M8 \times 0.75$	1 ~ 2N·m		
	R1/8	4.5 ~ 6.5N·m	White	
Taper pipe thread	R1/4	7 ~ 9N·m		_
Taper pipe triread	R3/8	12.5 ~ 14.5N·m	vviille	
	R1/2	20 ~ 22N·m		
Unified thread	No.10-32UNF	1 ~ 1.5N·m	_	SPCC+NBR、SUS304+NBR
	1/16-27NPT	4.5 ~ 6.5N·m		
National Pipe	1/8-27NPT	4.5 ~ 6.5N·m		
Thread Taper (American	1/4-18NPT	7 ~ 9N·m	White	_
standard)	3/8-18NPT	12.5 ~ 14.5N·m		
	1/2-14NPT	20 ~ 22N·m		

<sup>\*</sup> These values may differ for some products. Refer to each specification as well.

- 9. Instructions for removing a fitting
  - When removing a fitting, use proper tools to loosen a hexagonal-column or an inner hexagonal socket. When inserting a hex key into the inner hexagonal socket of the fitting, be careful so that the tool does not touch lock-claws. The deformation of lock-claws may result in a poor performance of systems or an escape of the tube.
  - ② Remove the sealant stuck on the mating equipment. The remained sealant may get into the peripheral equipment and cause malfunctions.
- 10. Arrange piping avoiding any load on fittings and tubes such as twist, tensile, moment load, shaking and physical impact. These may cause damages to fittings, tube deformations, bursting and the escape of tubes.
- 11. Instructions for handling a fitting
  - ① Impact caused by dropping or the like may lead to damage to the product and a fluid leakage.





# Common Safety Instructions for Fittings

Before selecting or using PISCO products, read the following instructions. Read the detailed instructions for individual series.

# 

1. Use PISCO products within the range of the specifications for each series. Consult with PISCO for use outside the specifications.

# 


1. A bulkhead nut of Bulkhead Union (PM), Bulkhead Union P (PMP), and Bulkhead Union Elbow (PML) should be tightened within the specified tightening torque range.

# Bulkhead nut tightening torqu

Carios	Tube size	Tightenii	ng torque
Series	Tube size	Bulkhead Union (PM)	Bulkhead Union P (PMP)、Bulkhead Union Elbow (PML)
	4	12.0 ∼ 14.0N·m	0.4 ~ 0.6N·m
	6	18.0 ~ 21.0N·m	0.9 ~ 1.1N·m
Tube Fitting	8	18.0 ~ 21.0N·m	1.1 ~ 1.3N·m
Tube Fitting	10	19.0 ~ 21.0N·m	2.3 ~ 2.7N·m
	12	19.0 ~ 21.0N·m	2.7 ~ 3.3N·m
	16	42.0 ~ 54.0N·m	_
	1.8	0.8 ~ 1.0N·m	
	2	0.8∼1.0N·m	
Tube Fitting Mini	3	2.5~3.5N·m	_
	4	5.0 ~ 7.0N·m	
	6	12.0 ∼ 14.0N·m	

- 2. If an object between the bulkhead nut and fitting body is deformable or has oil on its surface, the nut may loosen after tightening.
- 3. PISCO pneumatic fittings are designed for use with tube inserted. Air supply without tube insertion such as air flushing may cause an elastic sleeve to fly out of the fitting.









# Malke-to-order products

PISCO offers make-to-order products to support customer's various requirements such as special specifications, and special appearances.


# **Special Options**

- Characteristics
  - Color option Light-gray color option for resin body and release-ring.
  - Seal rubber material option Seal Rubber Selection: FKM or EPDM.
  - Oil-free option Suitable for Oil-free Environment.
  - Release-ring color option Changeable to Red Color
  - Non-purple option Suppress CU ion and F ion.
    - \* Note: With this option, Check Valve and Stop Fitting, etc. do not have marking on the brass parts. Be careful when piping.









# 1) Body color

Code	W	No code
Body color	Light-gray	Standard color

\* . W: Release-ring color is light-gray

# ② Seal rubber material

Code	-F	-E	-HN	No code
Material	FKM	EPDM (Oil-free)	HNBR	Standard seal rubber

- \* 1. FKM: Release-ring color is brown. Non-purple option is not available with FKM option.
- \* 2. EPDM: All oil-free. Release-ring color is yellow.
- 💥 3. EPDM: Not available for Thread size M3, M6 and Fittings with Inch sized Tube dia.

# 3 Lubrication

Code	-D	-P	No code
Option	Oil-free	Non-purple	Standard lubrication

- \* 1. Oil-free : Release-ring color is yellow.
- ※ 2. The products with oil-free option are assembled without intentional use of lubrication through its production process. It may cause problems such as degradation of airtightness and increase of friction.
- \* 3. Non-purple option is not available with FKM option. No sealock coat is provided on the thread.

# 4 Release-ring color

Code	-RR	No code
Color	Red	Standard color

- \* See next page for "Reference Chart of Special Option" .
- \*. Contact the nearest sales office for the price.

FITTING



# ■ Reference Chart of Special Option

○ : Available、× : Not available													
		Standa	ard spe	cificatio	on				Specia	l speci	fication		
	Dody Color and												4
Series	Body Color and						Body color						Release ring color
	Packaging /						Light-gray	FKM	EPDM	HNBR	Oil-free	Non-Purple	Red
	Cleaning option						W*1	-F*2	-E*3	-HN	-D*4	-P*2	-RR
Tube Fitting Standard Series	Standard	Black	Black		Turbin		×	O*5					
	Light-gray	Light-gray	Light-gray		oil	With	Std. option		0		0		0
	Clean-room Pkg		Light-blue	NBR	Fluorochemical sealock	×		O*6		○*6			
	Light-gray + Clean-room pkg	Light-gray	-		grease	coat	Std. option	_		_		×	×
	Clean washing + Clean-room pkg	Light-gray	Light-blue		Oil-free		×	×	O*6		Std. option		0
Tube Fitting Mini Series	Standard	Black	Black		Turbin		×	O *5,*10	0			_	
	Light-gray	Light-gray			oil	With	Std. option		O*10		0		0
	Clean-room Pkg		Light-blue	NBR	Fluorochemical	COAT Std. o	×	O*10		○*10	○*6		Ŭ
	Light-gray + Clean-room pkg	0 0 7	Light-gray		orease		Std. option		O*10		0	×	×
Tube Fitting Stainless	-55)	0 0 7	Dark-		Turbin			Std.	_		_		
SUS304 Series	_	Black	blue	FKM	oil	coat	×	option	O*7	0	O*7	×	_
Tube Fitting Stainless SUS303	Standard	Black	Dark-blue			With sealock	0	0	_	Std.	O*7	0	
Equiv. corrosivity	Clean washing + Clean-room pkg	Black	Dark-blue	HNBR	Oil-free	coat	×	×	O*7	option	Std. option	×	0
Tube Fitting EG Series	—	Black	Black	NBR		With sealook coat	×	0	O*8	0	() *8	0	_
24 001100		Bidok	Didok	HNBR	Turbii oii	With	- 1	_		Std. option			
Tube Fitting Brass Series	_	_	_	FKM	Turbin	sealock	×	Std. option	×	—			×
TODO TRUMB DI GOS OCITICO				NBR	oil	coat	^	— Old. option	^				^
Tube Fitting				INDIT	Turbin	With sealock							
Long Series	_	_	Black	NBR	oil	coat	×	○*5	0	0			0
Main Block	Standard	Black	Black		Turbin	With sealock	×	O*5					
Wall Block	Light-gray	Light-gray	Light-gray	NBR	oil	coat	Std. option	0	0	0	_	×	0
Connector	Ligiti-gray	Black	Black	NBR	Turbin oil	COAL	X	O*5	0	0	0	X	0
Speed Controller Series	Standard	Black	Black	NDN	Turbin		×	O*13				^	
Speed Controller Series	Light-gray	Light-gray			oil	With	Std. option	0.1	O*10			0	0
		0 0 7	Light-gray	NBR		sealock	× ×	*10,*11	() ±6,±10	O*10,*11	_		0
	Clean-room Pkg	Light-gray	Light-blue	- 1	Fluorochemical	coat		*12	O*10			×	~~
	Light-gray + Clean-room pkg	Light-gray	Light-gray		grease	Marie and all	Std. option		0-10	Obel			×
Speed Controller SUS303 Equiv. corrosivity	_	Black	Dark- blue	HNBR	Turbin oil	With sealock	0	O*11,*12	O*7	Std.	_		0
	01	District				coat		() *5,*12		option			
Needle Valve Series	Standard	Black	Black		Turbin	With	X Ctd antion	0 ~5,~12	0				
	Light-gray	Light-gray	Light-gray	NBR	oil	sealock	Std. option	O*12	O*6	0	_		0
	Clean-room Pkg	Light-gray	Light-blue		Fluorochemical	coat	×	0.12				×	
Fired suffice faint Contra	Light-gray + Clean-room pkg	0 0 7	Light-gray	NDD	grease	un	Std. option		0				X (**)
Fixed orifice joint Series	_	Black	Black	NBR		With sealook coat	0	0	0	0	0	0	
Regulator	_	Black	Black	NBR		With sealook coat	X	×	×	×	×	0	0
Check Valve (metal body)	-	-	Black	NBR	Turbin	With sealock	×	0	×	×	_		0
Check Valve (resin body)		Light-gray	Light-gray		oil	coat	Std. option					_	
Low cracking				HNBR				0	0	Std.			
pressure Check	_	Light-	Light-	(Elastic sleeve)	Turbin	_	Std.	(Elastic sleeve)	(Elastic sleeve)	option		×	0
Valve		gray	gray	FKM	oil		option	Std.	×	×			Ü
				(Poppet value packing)				option	(Poppel valve packing)	(Poppet value packing)			
*1. When light-gray (-\	M) is selected	for body	color t	he relea	SO.	*5 Rel	ease-rin	a color.	Brown				

- \*1. When light-gray (-W) is selected for body color, the releasering color of metric (mm) tube dia. is light-gray even for combination with any other options, except when Red color (-RR) is selected.
- \*2. Non-purple (-P) option is not available with seal rubber material FKM. No Sealock coating for Non-purple option.
- \*3. For EPDM (-E) specification of sealing material, the product is assembled as oil-free specification. The color of release-ring of metric (mm) tube size is yellow, except the combination with light-gray specification, which has lightgray release-ring. EPDM (-E) specification is not available for the products with M3 or M6 threads or inch tube dia.
- \*4. Release-ring color: Yellow. When with light-gray specification, the release-ring color is light-gray.

- \*5. Release-ring color: Brown.
- \*6. Release-ring color: Light-blue.
- \*7. Release-ring color: Dark-blue.
- \*8. Release-ring color: Black
- \*9. Release-ring color: Red is not available with body color Light-gray.
- \*10. Not available for Tube dia. Ø1.8mm and Ø2mm.
- \*11. Not available for Low cracking pressure type.
- \*12. Not available for the products with M3 thread.
- \*13. See \*5, \*10, \*11 and \*12.
- \*14. Applicable types: JSC, JSS and JSM for Standard Series, JSC-H for High Flow Series, JSC-L and JSS-L for Low Flow Series, JKC and JKL for Constant Flow Series.





# Reference chart of Appearance Color Combination with Special Options (Fitting with Metal body)

	Resin color			Seal rubbe	er material	Lubrication Release-ring color		
Series							-RR	
				FKM	EPDM		Red	
	_	(mm size)			•	•	•	
		(inch size)						
Tube Fitting Standard Series	Light-gray	(mm size)				8		
Tube Fitting Mini Series	Clean-room Pkg	(mm size)						
		(inch size)						
	Light-gray + Clean-room pkg	(mm size)		-		8		
Tube Fitting	Clean washing	(mm size)	-			Std. option		
Standard Series	Clean-room pkg	(inch size)				Std. option		
Tube Fitting Stainless SUS304 series	_	(mm size)		Std. option				
	_	(mm size)						
Tube Fitting Stainless SUS303 Equiv. corrosivity	Light-gray	(mm size)						
	Clean washing + Clean-room pkg	(mm size)				Std. option		



Reference chart of Appearance Color Combination with Special Options (Fitting with Resin body)

Reference chart of Appearance Color Combination with Special Options (Fitting with Resin body)										
							Release-ring color			
							-RR			
	Option	(mm size)	010	FKM	EPDM	Oil-free	Red			
Tube Fitting Standard Series Tube Fitting Mini Series	_	(inch size)								
	Light-gray	(mm size)	OF E	OF G	IF &	OF S	0			
	_ig.iv g.wy	(inch size)	B	F	B	F				
	Clean-room Pkg	(mm size)	IF &	OF E	IF &	OF E	0			
		(inch size)	F	F	T C	F				
	Light-gray + Clean-room pkg	(mm size)	OF CO		T.	The second				
Tube Fitting	Clean washing	(mm size)	(F		IF &	Std. option	0			
Standard Series	Clean-room pkg	(inch size)	F		F	Std. option				
Tube Fitting Stainless SUS304 series	_	(mm size)		Std. option						
Tube Fitting Stainless SUS303 Equiv. corrosivity	_	(mm size)					0			
	Light-gray	(mm size)	OF STREET	A.	OF STREET	of Contract of the Contract of	0			
	Clean washing + Clean-room pkg	(mm size)				Std. option	1			





Reference chart of Appearance Color Combination with Special Options (Speed controller and Needle Valve)


	Resin color			Seal rubbe	er material	Release-ring color			
Series						-RR			
	Option				EPDM	Red			
	_	(mm size)		1					
	_	(inch size)							
	Light-gray	(mm size)	11	01	11				
Speed Controller Series Needle Valve Series		(inch size)							
	Olassa was Silva	(mm size)							
	Clean-room Pkg	(inch size)							
	Light-gray + Clean-room pkg	(mm size)	01	01	12				

760



# **Space-Saving Options**

- Characteristics
  - Suitable for Installing in Limited Spaces.
- Model Designation (Example)



# ① Type

Code	Туре	Code	Туре	Code	Type	
L	Elbow	В	Branch Tee	D	Run Tee	

2 Tube dia.

Code	8	10		
Size (mm)	ø8	ø10		

# (3) Thread size

Thread size	Taper pipe thread							
Code	01	02	03					
Size	R1/8	R1/4	R3/8					


762












Unit: mm

Model code	Tube O.D. øD	R			Tube end C		Hex. H			Weight (g)
PL8-01M		R1/8	8	22.5		18.5	12		15	11.9
PL8-02M	8	R1/4	11	25.5	18.1	19.5	14	21.9		17.5
PL8-03M		R3/8	12	26.5		20.2	17			27.9
PL10-02M	10	R1/4	11	27	20.2	21	14	14 17 24.4	18	20.9
PL10-03M		R3/8	12	28	20.2	21.7	17			28.8

 $\ensuremath{\text{\#}}$  . "L" is a reference value for height dimension after tightening thread.







Unit: mm


Model code	Tube O.D. øD	R			Tube end C		Hex. H			Weight (g)
PB8-01M		R1/8	8	22.5		18.5	12		15	12.8
PB8-02M	8	R1/4	11	25.5	18.1	19.5	14	21.9		18.2
PB8-03M		R3/8	12	26.5		20.2	17			26.1
PB10-02M	10	R1/4	11	27	20.2	21	14	24.4	18	22.3
PB10-03M		R3/8	12	28		21.7	17			30.4

 $\mbox{\%}$  . "L" is a reference value for height dimension after tightening thread.

TUBE







Unit: mm

Model code	Tube O.D. øD	R	А	В	Tube end C	L	Hex. H	Е	øΡ	Weight (g)
PD8-01M		R1/8	8	44.2		18.5	12			11.9
PD8-02M	8	R1/4	11	47.2	18.1	19.5	14	21.7	15	17.5
PD8-03M		R3/8	12	48.2		20.2	17			25.3
PD10-02M	10	R1/4	11	52.3	20.2	21	14	25.3	18	21
PD10-03M		R3/8	12	53.3	20.2	21.7	17	20.3	10	28.8

\* .L" is a reference value for height dimension after tightening thread.